



Index	Pièce / Part	Désignation	Description
1	506 608	COUVERCLE	LID
2	505 010	FOND AMOVIBLE	BOTTOM TRAY
3	502 331	PANIER SANS FOND	BOTTOMLESS TRAY
4	505 011	BOL A RIZ+COUVERCLE	RICE BOWL+LID
5	505 502	COUVERCLE BOL A RIZ	LID RICE BOWL
6	502 335	PANIER AVEC FOND	TRAY WITH BOTTOM
7	502 355	BLOC CHAUFFANT COMPLET	STEAMER PLATE ASSY
8	502 356	PCB ALIM+ SUPPORT *	PCB POWER+BOX *
9	505 642	THERMOSTAT 130°	THERMOSTAT 130°
10	505 644	FUSIBLE	FUSE BROWN WIRE
11	505 628	BOITIER COMMANDE COMPLET	CONTROL BOX ASSY
12	502 359	BASE	MAIN BODY
13	502 398	BOUTON DE COMMANDE	SWITCH KNOB ASSY
14	502 414	FICHE+PROTECTION	POWER SOCKETS+CAP
15	505 022	CORDON D'ALIMENTATION	POWER CORD
16	502 444	ENSEMBLE FIXATION CORPS/BLOC	BODY MOUNT+SCREW
17	502 447	ENSEMBLE SOCLE+PIEDS+VIS	BOTTOM COVER+FEET+SCREW
18	502 467	VIS X 9	SCREW X 9
19	505 686	QUADRI	CARTON
20	408 440	POLYSTYRENE	POLY FOAM
21	501 920	SUREMBALLAGE	OVERPACK
22	506 892	BASE COMPLÈTE	COMPLETE BASE
		* SI PLATINE 6 BROCHES, COMMANDER L'ENSEMBLE 505 628	
		* IF PCB HAS 6 PINS, ORDER ASSEMBLY 505 628	